



Polaris URC1090 Big Button TV Remote Guide

This guide will help you program this remote to your TV and help you learn to find and uses its basic features. Contact TCC if you need assistance or have questions.

Programming to your TV:

Programming the remote to your TV will allow you to the TV on and off and control the volume from the TCC remote. Make sure to aim your remote at the TV while doing this.


1. Press the TV button or try the Volume up/down to see if it's already programmed. If the TV goes off, or the volume goes up/down, it's already programmed! You're done! If not, continue with the steps below:



2. Press the TV button.



3. Press and hold the Setup button until the TV button blinks twice (one long blink means it failed).



4. Type 991.



5. Press the Channel Up button until the TV turns on or off.



6. Press Setup to save the code.

Diagram of the remote and its buttons is on the other side >

Quick Guide to Buttons on the Remote



POWER/SETUP CONTROLS

1. TV button turns your TV on and off
2. SETUP (green) button used for remote control programming
SETUP also makes the buttons light up when using the remote
3. CBL button turns your cable box on and off

PLAYBACK CONTROLS

4. PLAY and PAUSE to play or pause a recorded program or Live TV
REW and FF buttons move ahead or back through a recorded show
RECORD press to record selected program
STOP will stop playback of a recorded program
5. LIST will show a list of options for your program
REPLAY will go back 30 seconds
6. LIVE will go to Live TV after pausing or rewinding Live TV

NAVIGATION KEYS

7. MENU displays main cable menu
8. INFO displays information on current selected program
9. OK/SEL to choose or select what is highlighted on the TV
10. GUIDE displays program guide
11. EXIT closes current menu

OTHER KEYS

12. VOL turns the volume up and down
13. CH + - to go up and down the channels
14. LAST returns to the previously selected channel
MUTE will mute the volume (press again or Vol up to unmute)
15. Color keys for special functions through the Menu button
16. DAY - + and PAGE - + to scroll through guide by day or page
(After pressing Guide button)
17. Number keys to type channel directly
VOD for video on demand (not offered by TCC)
CC for turning Closed Captioning on and off

